

Smart Lock

User Manual

LHL -PFR




Special Attention:

- 1. Mechanical keys please keep outdoor, just in case keys lock in doors.*
- 2. Please replace for the battery when low wattage alarm.*
- 3. Reading this manual carefully before installation, and keep it for future reference.*

1. Introduction

1.1.Lock structure



1.2.Packing List

💡 Check the following drawing to check whether the package contains all the parts


NO	Name	Qty	NO.	Name	Qty
1	Front Panel	1	10	Sliding Screws:M5*11mm	2
2	Back Panel	1	11	60mm Square shaft	1
3	Mortise	1	12	80mm Square shaft	1
4	Card	3	13	M5*30mm Screw	2
5	Waterproof Rubber Plate	2	14	M5*40mm Screw	2
6	Strike&Strike Box	1+1	15	M5*50mm Screw	2
7	Screw Stubs:M5*30mm	2	16	M5*60mm Screw	2
8	Mortise Screws:10*5mm (For Aluminum Door)	4	17	User Manual	1
9	Mortise Screws:25*4mm (For Wooden Door)	4	18	U-Clip	1

1.3.Specifications

<i>Suitable for Models</i>	BONDI	<i>Doors Applicable</i>	Aluminum door Wooden door
<i>Materials</i>	Handle: SS304 Panel: SS304	<i>Working Voltage</i>	6V/4x AAA Batteries
<i>Lock Weight</i>	2.5KG	<i>Door Thickness to Fit</i>	35-65mm
<i>Unlocking Way</i>	Bluetooth Fingerprint(option) Password Card Mechanical key Gateway(option)	<i>Data Capacity</i>	Fingerprint: 200 Password: 150 Card: 200
<i>Color</i>	Silver Black	<i>Working Temperature</i>	-10℃-55℃
<i>Low Wattage Alarm</i>	Less than 4.8V	<i>Working Humidity</i>	0-95%

1.4.System Initialization


Open the cover plate of the front panel ,long press the "Reset" button on the back panel for 5s, press "000#",and the initialization is complete




2. Installation

2.1 Turn the handle

Notice: Adjust the handle according to the direction you open the door.




1、Turn the handle on the front panel
Loosen the inner hexagon screw of the handle counterclockwise




2、Remove the handle




3、After adjusting the direction of the handle, insert it into the handle seat and re-lock the hexagon screw of the handle to complete the turning



1、Turn the handle on back panel
Loosen the inner hexagon screw of the handle counterclockwise








2、Remove the handle



3、After adjusting the direction of the handle, insert it into the handle seat and re-lock the hexagon screw of the handle to complete the turning

2.2. Installation Diagram(For Nordic lock body)

Step 1 Install Mortise and Lock cylinder 	Step 2 Install Sliding Screw Casing  The arrow is in the same direction as the handle
Step 3 Install Back Panel and link wire 	Step 4 Install battery and back cover 
Step 5 installation complete 	

3. Operation

3.1. Registration



The software (iOS version) can be downloaded from the app store, and the Android version can be downloaded from the application store of Google play, Yingyongbao, Baidu, Ali, 360, Huawei, and Xiaomi.


3.2. Connect lock to the phone

- 1) please scan the QR code to download the app
- 2) You can also search for TTLock in the APP store(Google Play)to download
- 4) Register a new account (phone number or email) or login with an existing account.
- 5) Touch the lock screen to light, click "+ Add Lock"
- 6) The lock nearby will appear on the phone screen, Click "+"
- 7) Re-name the lock
- 8) The lock added successfully

TTlock users can register the account by mobile phone and Email which currently support 200 countries and regions on the world. The verification code will be sent to user's mobile phone or email, and the registration will be successful after the verification.

3.3. Add locks

TTLock supports multiple types of lock devices. The lock needs to be added by the app after entering the add mode. Generally, a lock that has not been added, as long as the lock keyboard is touched, it will enter the add mode. The default password is 123456 if not added by the phone




3.4. User Management

3.4.1. Bluetooth management

Make sure there is no problem with Bluetooth communication. After connecting the phone to the door lock as above, Click "  "to unlock.(the phone is within 5meters from the door lock)


3.4.2. Setting Passcode

Passcodes are also a way to unlock. After entering the passcode on the locked keyboard, press the unlock button in the lower right corner to unlock. Passcodes are divided into permanent, time-limited, single, clear, cycle, and custom.(You can share the Passcode to other user via WeChat、SMS、Email、Messenger、WhatsApp)




3.4.3. Send e-Key

Click on the "  " as shown in figure, you can send the eKey to other users of TTlock to authorize the unlock(the receiver must be download the APP and set up an account)→ Select e-key format (Timed, permanent, One-time, Recurring) → Enter recipient's account of TTlock,set the name and effective time of the eKey, Can choose to allow remote unlocking or disallowing, authorized administrator or not authorized, as shown in figure →Send→The recipient's account has Bluetooth unlock permission




3.4.4. Add card

Supports opening doors through various IC cards. Before an IC card is used to open the door, it needs to be added first. The adding process needs to be performed by the app beside the lock. The validity period of the IC can be set, it can be permanent, or it can be limited in time.



3.4.5. Add fingerprint

The premise that a fingerprint can be used to open a door is that it needs to be added first. The adding process needs to be performed by the APP beside the lock. The fingerprint expiration data can be set, it can be permanent, or it can be limited. After setting, you can modify its validity period.



3.4.6. e-Key management


Click "  " The manager can delete ekey, reset ekey, send and adjust the ekey, meanwhile he can search the lock record.

3.4.7. Passcode management

Click "  " All generated passwords can be viewed and managed in the password management module. This includes a password change, password deletion, password reset, and password unlock record.

3.4.8. Unlock records

Click "  " you can query your unlock record as shown in figure



3.5. Gateway management(Optional)

The TT lock is directly connected via Bluetooth, that is why it is not attacked by the network. The gateway is a bridge between smart locks and home WIFI networks. Through the gateway, the user can remotely view and calibrate the lock clock, read the unlock record. Meanwhile, it can remotely delete and modify the password.

3.5.1. Add Gateway

Light Status




When the gateway is powered on:


- Light flashes alternately in red and blue: Stand-by mode, ready for pairing
- Blue light: Working mode
- Red light: Network failure

Pair the Gateway with APP

1 Activate the APP




2 Press "≡"




3 Select [Gateway]



4 Select [G2]



5 Plug in the gateway and power it on, while the light flashes alternately in red and blue



6 Press "+" sign



7 Add Gateway



8 Select the network and fill in the password



9 Add complete

⚠ Notice: If times out, please power off and try it again.

3.5.2. Manual

After a short period of time, you can see which locks are in their coverage in the app. Once the lock is bound to the gateway, the lock can be managed through the gateway

4.FAQ

	1) How to read operation records?	In the Records of the main interface. .
	2) Why can't I unlock it after open the passage mode	You need to perform an unlock verification in any method, than the passage mode will take effect.
	3) What is the purpose of Auto Lock	You can set how long to lock after unlocking
Introduction	4) After installation, touch sensing keyboard, screen no respond	a) In this case, first check that the positive and negative electrodes of the battery have been installed upside down, whether the battery has enough power b) Remove the back panel and see if it's connected. c) To eliminate the above situation, you need to remove the lock ,check whether the wires of the lock body are squeezed, and the re-wire.
Installation		
Operation	5) Unable to register fingerprint	Check the fingers for dirt or wear, check the fingerprint head on the lock for dirt and oil stains, etc. Check to see if the fingerprint is working properly(Press to see if there is any responds.
F&Q	6) What is the reason why the smart lock consumes fast power?	a) Large standby power consumption b) Short circuit
Appendix	7) There is no response to pressing the handle on outside the door, and there is unlock normally on inside the door, but the verification is normal, and the motor is normal.	It may be the triangle direction on the clutch was error, please check correction.
	8) How many times will the passcode be locked? How long is it locked?	Enter the wrong password more than 5 times in a row, the keyboard is locked for 5 mins, Other ways to can open the door

Guarantee

Customer Name: _____

Customer Calls : _____

Purchase Date : _____

Product Name : _____

Product Model : _____

Note:

- ① *Please keep this card so that you can use it when you need warranty service.*
- ② *We provide you with a one-year warranty from the date of purchase.*
- ③ *This warranty service is valid for customers in any country in the world.*